



MONOWAVE (X) Rev 1  
Elby Designs  
Paul Maddox

269 (mm)

- Interchange R502 and C502
- Interchange R602 and C602
- Remove R403 and C403
- Fit wire link in position C403
- Bend back U406 pin 4 and 10 and connect to +5V
- Connect U202 pin 6 to U202 pin 10

- Remove pin 4 from U503
- Remove pin 4 from U603
- Short pin 4 and pin 5 of U503
- Short pin 4 and pin 5 of U603
- Connect U503 pin 19 to U506 pin 18
- Connect U603 pin 19 to U606 pin 18
- Cut AGND track to TAB of U2

- Remove U303
- Connect U303 pin2 to U303 pin 6
- Connect U303 pin 10 to U303 pin 11
- Remove U601
- Connect U601 pin 6 to TP201

<p><b>Elby Designs</b> Karing, NSW 2250 Australia www.elby-designs.com</p>	<p><b>MonoWave(X) Main Board</b></p>		
<p>All dimensions in millimeters unless stated otherwise.</p>	<p>(A3) Not to scale</p>	<p>Rev: 1</p>	<p>Date: 12/04/06</p>