



To disable Voltage Control:-
Remove D501 & D502
Replace R506 with a wire link



9 Follan Close
Kariong
NSW 2250
Australia

ASM-2

Voltage Controlled Low-Frequency Oscillator (1)

Size A4	FCSM No. 22/07/2008	DWG No. lfo1.schdoc	Rev A
Scale	Laurie Biddulph		Sheet 4 of 24