

## Programmer Settings for the ATMEGA16 and AVRSYNTH

The following pages are screenshots from AVR Studio 4 and show the various settings used whilst programming the ATMEGA16 for the AVRSYNTH .

Please note that some of these settings may not need to be set as shown for correct operation of the AVRSYNTH but are the settings used.





