



Adjust the values of R1102 and R1107 to give preferred modulation frequency.
 They should be different values to provide a small beat frequency.
 For optimum symmetry, $R1101 = 2 \times R1102$ and $R1106 = 2 \times R1107$
 Current values gives 50Hz and 55Hz



9 Follan Close
 Kariang
 NSW 2250
 Australia

Pixie - An EDP WASP Clone

Dual PWM LFO

Size A4	FCSM No. 29/04/2011	DWG No. PWM-LFO.s11	Rev B
Scale	Laurie Biddulph		Sheet 11 of 20