




ES02 Preamp Detector

Construction Guide

Revision 1.0

March 20th, 2016



Elby Designs - Laurie Biddulph

9 Follan Close, Kariong, NSW 2250, Australia

elby_designs@ozemail.com.au <http://www.elby-designs.com>

ES02 Preamp Detector

Construction of the ES02 requires the assembly of 1 board:-



Column 1 - ES02 PCB ([3D Model](#))

Constructors should refer to the printed Component Overlay for any specific comments regarding the board assembly, the Bill of Materials for the current value of all components and [General Construction Notes](#) for general pcb assembly guidelines. You are advised to check all of these documents on our website to ensure you have the latest copy.

1. Assemble the 2 Carrier Board assemblies
2. Fit all components to the boards following normal assembly guidelines except sub-assemblies J102 and J202
3. Mount the sub-assemblies on to their headers and then offer the assembly up to the front panel and secure using the supplied nuts
4. Solder both sub-assemblies in to place

Calibration

The ES02 does not require any calibration or set-up



Elby Designs - Laurie Biddulph

9 Follan Close, Kariong, NSW 2250, Australia

elby_designs@ozemail.com.au <http://www.elby-designs.com>